

Rocket Two In One

Instruction Sheet

Lighting Cooker

Fill cooker with water (12 litres)

Make sure cooker is always full of water while in use to stabilise unit.
Use Paper, coconut husk, dry leaves or light dry sticks.

Place these in tube, on top of cooker, careful not to overfill.
Light from front tube and start placing small dry sticks in top until fire is established.
Place sticks for fire on top of plate in front tube crossing sticks so as not to block airflow
Keep pushing sticks in as fire burns.
Place wind shield on top with gap facing to rear of cooking so air flows through from front to back
Continue to feed fire with dry selected sticks to maintain strong burn.

Cleaning of cooker

Rinse each time you refill with water
Clean fire tube once a month to stop soot build up
Use a brush, handful of small bush sticks or sand

What you can use in cooker

Bush sticks best up to 10mm
Coconut husk & shell
Wood shavings
Charcoal
Coal
Dung
Dry corn cob

What can you cook with

Pots
Steamers
Hot plate
Frying pan
Wok

